

Standard Wrenches



Model DS56 Wrench

- DS56



Model F3R Wrench

- F3
- F3QR
- F3Res
- DH Dry



Model H Wrench

- GL112
- GXLO
- GVELO
- GFR VELO
- MBEC



Model J1 Wrench

- J
- JL



Model W13 Wrench

- K5.6 sprinklers with pre-installed D-1, D-3, D-4, and D-5 guards



Model W14 Wrench

- K8.0 sprinklers with pre-installed D-1, D-3, D-4, and D-5 guards
- Sprinklers with pre-installed F series guards




Model W15 Wrench

- Sprinklers with pre-installed D-6, D-7, D-8, and D-9 guards




Model W2 Wrench

- AH
- DD
- DH, except Dry
- F1
- F1FR
- F1Res
- F1S
- G
- GFR
- GP
- KFR
- LT56,
- LT56L
- KRes
- WP56
- WP56L



Model W5 Wrench

- HL-22
- N25
- N252EC
- TNL280
- P22
- P25
- N28



Model W16 Wrench

- P22 with pre-installed D-14 guard
- P25 with pre-installed D-14 guard
- HL22 with pre-installed K22 guard
- N25 with pre-installed K25 guard
- N252EC with pre-installed K25 guard

Recessed/Concealed Wrenches



Model FC Wrench

- G5-56 Dry
- G5 without cap
- RFC without cap
- LT56C without cap
- WP56C



Model RJ Wrench

- J
- JL



Model W10 Wrench

- RFC49plus



Model G4 Wrench

- F4FR
- G4
- G4XLO



Model W1 Wrench

- KFR
- KRes



Model W11 Wrench

- Plastic limited-use wrench for spare sprinkler cabinet - RFC49plus without cap



Model G6 Wrench

- G6
- RFS



Model W3 Wrench

- G5 with wrench-able cap
- RFC (except RFC49plus) with wrench-able cap
- LT56C with wrench-able cap



Model XLO2 Wrench

- F3
- F3QR
- F3Res
- DH Dry
- GFR VELO



Model N Wrench

- N252EC



Model W4 Wrench

- F1Res
- F1, F1LL,
- F1SS
- F1FR,
- F1FRLL,
- F1FRSS
- F1S
- LT56,
- LT56L
- GFR
- KFR
- KRes



Model ZX Wrench

- XL Pendant



Model RC1 Wrench

- G Recessed



Model W8 Wrench

- Plastic limited-use wrench for spare sprinkler cabinet - RFC (except RFC49plus) without cap



Model ZX-HSW Wrench

- XL HSW